# Recovery of the DSL-G225 Retail/Telkom

You will know that your router is in recovery mode when the power light is red and when you use a LAN cable to one of the 4 yellow LAN ports, the LAN port lights up.

## Step 1: Change PC IP address.

Change the IP address of your ethernet connection to 192.168.1.5, subnet mask is 255.255.255.0 and a default gateway of 192.168.1.1. Here is a link to see steps to do so. <u>https://kb.netgear.com/27476/How-to-set-a-static-IP-address-in-Windows</u>

#### Step 2: Get to recovery page.

Insure there is a cable connected between the router on a yellow port and a PC. Then open a web browser and go <a href="http://192.168.1.1">http://192.168.1.1</a>

If you cannot get to this page you will need to return the device to a Telkom or Retail store so that it can be sent in for repairs.

÷	→ C () Not secure   192.168.1.1	☆	ト	0	9	
	Update Software					
	Step 1: Obtain an updated software image file.					
	Step 2: Enter the path to the image file location in the box below or click the "Browse" button to locate the image file.					
	Step 3: Click the "Update Software" button once to upload the new image file.					
	NOTE: The update process takes about 2 minutes to complete, and your Router will reboot.					
	Software File Name: Choose File No file chosen					
	Update Software					

#### Step 3: Upload recovery firmware.

Here is the link to download the recovery firmware which you will upload with the router's recovery page.

ftp://ftp.d-link.co.za/DSL/DSL-G225/Recovery/GURN5.QT216E-C-DL-R6B029-DAF.EN(AF\_3.13\_T15)\_whole\_image.w

Or

http://downloads.d-link.co.za/DSL/DSL-G225/Recovery/GURN5.QT216E-C-DL-R6B029-DAF.EN(AF\_3.13\_T15) whole image.w

## Step 4: Go back to http://192.168.1.1

Login with admin as the username and admin as the password.

Product Page: DSL-G225 Firmware Version										
D-Link										
DSL-G225	SETUP	ADVANCED	MAINTENANCE	STATUS		HELP				
System	FIRMWARE UPDA		Helpful Hints Please Note: This page							
Firmware Update Access Controls	Step 1: Obtain an updated firmware image file from your ISP.     Step 2: Enter the nath to the image file location in the box below or click the "Browse" button to									
Diagnostics System Log	locate the image file.									
Logout	NOTE: The update pro	cess takes about 2 minutes	ut 2 minutes to complete, and your DSL Router will reboot. r before the update is complete.			support. If your router is working without issue, there should be no need to update your firmware. This information is just for your reference as it is				
	FIRMWARE UPDATE         Current Firmware Version : AF_3.13_T15         Current Firmware Date : Jan 4 2017         Firmware File Name : Choose File GURN5.QT21)_upgrade									
		Update F	Firmware							

Navigate to "maintenance" and then "Firmware update". Here you will update the correct firmware for your router.

For Telkom routers use the file from this link:

ftp://ftp.d-link.co.za/DSL/DSL-G225/Telkom/Firmware/GURN5.QT216E-C-DL-R6B025-DAF.EN(AF\_3.09\_T15)\_upgrade

OR

http://downloads.d-link.co.za/DSL/DSL-G225/Telkom/Firmware/GURN5.QT216E-C-DL-R6B025-DAF.EN(AF\_3.09\_T15)\_upgrade

For Retail routers use the file from this link:

ftp://ftp.d-link.co.za/DSL/DSL-G225/Retail/Firmware/AF\_3.03\_R05/GURN5.QT216E-C-DL-R6B013-GE.EN(AF\_3.03\_R05)\_upgrade

OR

http://downloads.d-link.co.za/DSL/DSL-G225/Retail/Firmware/AF\_3.03\_R05/GURN5.QT216E-C-DL-R6B013-GE.EN(AF\_3.03\_R05)\_upgrade

The file will upload then the router will reboot.

### Step 5: Use Putty to reset router.

You will then need to use a program to Telnet into the router (Such as PuTTY which can be downloaded from this link: <u>ftp://ftp.d-link.co.za/DSL/DSL-G225/Recovery/putty.exe</u>)

OR

http://downloads.d-link.co.za/DSL/DSL-G225/Recovery/putty.exe

#### To do this, open PuTTY and enter the settings as shown in this screenshot:

🕵 PuTTY Configuration		$\times$
Category: Session Codeging Category: Session Codeging Category: Session Cogging Category: Selection Colours Colours Connection Proxy Telnet Rlogin Setal	Basic options for your PuTTY set         Specify the destination you want to conner         Host Name (or IP address)         192.168.1.1         Connection type:         Raw         Telnet         Raw         Telnet         Raved Sessions         Default Settings         Close window on exit:         Always         Never         Only on close	ct to Port 23 Contemport 24 Co
About	Open	Cancel

Once the Telnet connection is open, use the username: admin and password: admin to login

When logged in, type in the command 'restoredefault'

The router will reboot.

You will need to change your IP settings back to 'Obtain an IP address automatically' at this point (Control Panel -> Network and Sharing centre -> Change adapter settings -> Local area connection -> Internet Protocol Version 4)

After this reboot the router will be recovered and you will be able to set it up again using the setup wizard