
## **Basic setup guide for QoS**

(Can be used with DSL-G2562DG and the DWR-956M)


**Quality of service** (**QoS**) is the description or measurement of the overall performance of a service, such as a telephony or computer network or a cloud computing service, particularly the performance seen by the users of the network.

Login to the router. Default IP address is <a href="http://10.0.0.2">http://10.0.0.2</a>




Default login username and password is "admin".


1) Go to Advanced setup  $\rightarrow$  Quality of Service  $\rightarrow$  QoS Queue.



2) Go to Advanced setup  $\rightarrow$  Quality of Service  $\rightarrow$  QoS Classification.





Add a Flow rule.





## DSL-G2562DG Home Gateway







## DSL-G2562DG Home Gateway

Classification List



Number	Enable	Traffic Type	Mark	Queue	Action	
No Rule Found!						
Add Traffic Type						
Number	Enable	Classification Rules		Mark	Queue	Α
1	Enable	Destination Port: 80~80 Protocol: TCP		802.1P: -	3	6
Add Flow						