

Audio Internet Camera

Home **Advanced** Tools Status Help

LAN Settings
The IP address of the Camera

- DHCP Client
- Static IP**

IP Address	192.168.0.20
Subnet Mask	255.255.255.0
Default Gateway	192.168.0.1
DNS	192.168.0.1

Apply Cancel Help



DCS-950

Video

User

LAN

PPPoE

DDNS

URL JPG

Logout

Go to Advanced

Choose Static

IP of Camera

IP of ROUTER

Go to LAN

Make sure your range is exactly the same as in this case it's the zero range

Click APPLY when finished