



System

Wireless

Network

User

Home

Configuration

Tools

Help

Device Status

Server Name : PS-100208
Model : DP-G321
Firmware Version : 2.00 (2005-06-27)
MAC Address : 00 11 95 10 02 08
IP Address : 192.168.0.10 (Manual)
Up Time : 0 days, 00:01:38

Printer Status

USB1 : Printer Name : PS-100208-U1
Printer Speed : Full Speed (12M bps)
Printer Status : Off line

Total Print Jobs : 0
Total Print Size : 0 KBytes

Printing Status : Idle
Name :
MAC :
IP :
Protocol :
Spooling Size : 0 Bytes
Printing Size : 0 Bytes

USB2 : Printer Name : PS-100208-U2
Printer Speed : Full Speed (12M bps)
Printer Status : Off line

Total Print Jobs : 0
Total Print Size : 0 KBytes

Printing Status : Idle
Name :
MAC :
IP :
Protocol :
Spooling Size : 0 Bytes
Printing Size : 0 Bytes

LPT : Printer Name : PS-100208-P3
Printer Speed : High

Printer Speed : High
Printer Status : Off line

Total Print Jobs : 0
Total Print Size : 0 KBytes

Printing Status : Idle
Name :
MAC :
IP :
Protocol :
Spooling Size : 0 Bytes
Printing Size : 0 Bytes

Ethernet Status

Link : Yes
Speed : 100M bps
Full Duplex : Yes

Tx Packets : 1061
Tx Errors : 0
Rx Packets : 817
Rx Errors : 0



Refresh



System

Wireless

Network

User

Home

Configuration

Tools

Help

Wireless Status

Connection Mode : Infrastructure
Link : No
SSID : default (MAC : 00 00 00 00 00 00)
Channel : 6
Transmission Rate : 54M bps
Encryption : No

Tx Packets : 0
Tx Errors : 0
Rx Packets : 0
Rx Errors : 0



Refresh



System

Wireless

Network

User

Home

Configuration

Tools

Help

Auto IP

DHCP/BOOTP : Disable (IP : 0.0.0.0)
UPnP : Enable (IP : 169.254.2.8)
MAC Rendezvous : Enable (IP : 169.254.2.8)

TCP/IP Printing

LPR Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes

Port (9100/9101/9102) Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes

IPP Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes

FTP Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes

Microsoft Network Printing

SMB (Over NetBEUI) Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes

SMB (Over NBT) Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes

MAC AppleTalk Printing

AppleTalk Printing : Status : Running
Total Print Jobs : 0
Total Print Size : 0 KBytes



Refresh



System

Wireless

Network

User

Users Printing Log

MAC	IP	Name	Jobs	Size(KBytes)
-----	----	------	------	--------------



System

Wireless

Network

User

SNMP

System Device

Server Name :

Location :

Admin Contact :

Password : New Password :

Confirm Again :

Port Setting

USB1 : Port Name :

Description :

PJL Printer :

USB2 : Port Name :

Description :

PJL Printer :

LPT : Port Name :

Description :

Speed :

PJL Printer :



Apply Cancel



System

Wireless

Network

User

SNMP

Wireless Interface

Connection Mode : Infrastructure
 Ad-Hoc

SSID : default

Wireless Channel : 6

Transmission Rate : Fully Automatic

Encryption

Disable

WEP Encryption

Length : 64bits 128bits

Format : ASCII HEX

Key 1 :

Key 2 :

Key 3 :

Key 4 :

Encrypt Data Transmissions Using : Key 1

Authentication Type : Open System Shared Key Both

Advanced Setting

Beacon Interval : 100 (ms)

Preamble : Long Short

Apply Cancel



System

Wireless

Network

User

SNMP

Home

Configuration

Tools

Help

TCP/IP

IP Address : Manually Assign
IP Address :
Subnet Mask :
Default Gateway :
 Automatically Assign

DNS Server Address : 1.
2.

UPnP : Enable Disable

MAC Rendezvous : Enable Disable

Second HTTP Port : Enable Disable
Port Number :
(For Remote Web Configuration and IPP Printing)

Microsoft Network

Workgroup :

AppleTalk

AppleTalk Zone :

USB1 : Chooser Name : PS-100208-U1
Printer Type :
PostScript Level : ▾
Font Group : ▾

USB2 : Chooser Name : PS-100208-U2
Printer Type :
PostScript Level : ▾
Font Group : ▾

LPT : Chooser Name : PS-100208-P3
Printer Type :
PostScript Level : ▾
Font Group : ▾



Apply



Cancel



System

Wireless

Network

User

SNMP

Printing Control

Enable User Printing Control : Yes No



Apply Cancel

Define Users

Add User : User Name : Add

MAC Address :

(Example : 00 80 C8 A1 B2 C3)

Printing Access : Yes No

Delete User : Delete

User List	Name	MAC	Printing Access
-----------	------	-----	-----------------

SNMP Management

Community 1 Name :

Access Right :

Community 2 Name :

Access Right :

Community 3 Name :

Access Right :



Apply Cancel



System

Wireless

Network

User

SNMP



Print Test

E-mail

Reset

Upgrade

Backup

Print Test

Port Selection

Print test function requires Native DOS mode support on your USB printer.

- USB1
- USB2
- LPT



Apply



Print Test

E-mail

Reset

Upgrade

Backup

E-mail Account

Print Server E-mail Address :

Outgoing E-mail (SMTP) Server Address :

Account Name :

Password :



Apply



Cancel

E-mail Notification

Enable e-mail notification for printer status changing : Yes No

Admin E-mail Address :

(Use ';' to separate multiple e-mail address)



Apply



Cancel

E-mail test will send an e-mail to Admin's e-mail address.
Do you want to test an e-mail account?

Test



Print Test

E-mail

Reset

Upgrade

Backup

Reset

This device will now be reset.



Apply

Factory Reset

All settings on this device will now be restored to the factory default.



Apply



Print Test

E-mail

Reset

Upgrade

Backup

Upgrade

Note: Please make sure that you use the correct firmware before you proceed. If you do not know which firmware you should use, please contact your local dealer for technical support.

Current Firmware Version and Date: 2.00 (2005-06-27)

Firmware Upgrade

Select A Firmware File :

Browse...



Apply



Cancel



Print Test

E-mail

Reset

Upgrade

Backup



Backup Device Configuration to File

Do you want to backup the configuration to file?



Apply

Restore Device Configuration from File

Select A Configuration File :



Apply



Cancel

Help

For US customer support, please visit us online at <http://support.dlink.com>

Home

- System
- Wireless
- Network
- User

Configuration

- System
- Wireless
- Network
- User
- SNMP

Tools

- Print Test
- E-mail
- Reset
- Upgrade
- Backup