

Home

Configuration

Tools

Help



System

Wireless

Network

User

SNMP

TCP/IP

IP Address :

Manually Assign

IP Address : 192.168.0.10

Subnet Mask : 255.255.255.0

Default Gateway : 192.168.0.1

Automatically Assign

DNS Server Address :

1. 4.2.2.2

2. 0.0.0.0

UPnP :

Enable Disable

MAC Rendezvous :

Enable Disable

Second HTTP Port :

Enable Disable

Port Number : 0

(For Remote Web Configuration and IPP Printing)

Microsoft Network

Workaroup :

WORKGROUP

STEP 1:
Go to
Configuration

Router IP

STEP 2:
Go to Network