D-Link
Building Networks for People

Test Report

-	Case No (R3) :	D20210624001
	Case Type :	New Firmware [Full Function Test]
	PLM No. :	DSTC2100115
	DUT :	DV-800 /HW:A1 /FW:1.00.045
	Description :	D-View 8 v1.0.0.45 Formal Release Test Report
	Test Engineer :	Aaron Pan , Mindy Chang , Martin Shen
+	R2 :	D20210412002
+	R1 :	D20210323007

Test Result Summary

Case No	Case Type	Test Cases	Pass	Fail	NA	Bug
D20210624001	New Firmware	596	324	4	268	5
D20210323007	New Firmware	86	73	8	0	0
D20210412002	New Firmware	337	178	6	72	1

Testplan Summary

Plan ID	Subject	Test Cases	Pass	Fail	NA	Bug
DKP2103024	TSD1_Switch_D-View8	67	49	4	65	
DKP2103025	TSD1_Switch_D-View8_Monitor	288	184	13	88	
DKP2103026	TSD1_Switch_D-View8_Configuration	106	54		101	
DKP2104004	TSD1_Switch_D-View8_Tools	56	56		43	
DKP2104007	TSD1_Switch_D-View8_Alarm	31	31		31	
DKP2106004	TSD1_Switch_D-View8_Reports	66	66			
DKP2106012	TSD1_Switch_D-View8_System	67	67			
DKP2106013	TSD1_Switch_D-View8_Template	27	27			
DKP2106014	TSD1_Switch_D-View8_Cluster	14	2		12	
DKP2106015	TSD1_Switch_D-View8_Other	40	39	1		
	Total :	762	575	18	340	0

Bug Summary

Bug ID	Bug Status	Fail Severity	Bug Description
			[D-View8][1.00.36][Dashboard/Analysis/PoE] The running status always displayed online even the PoE device was disconnected.
DBG21040331	NEW Fixing	S2:Minor	Peter Chan - 2021/04/20 09:35 Hi Aaron, I agree with RD's comment. However, the description will modify to prevent from confusing. As this is not a major issue, we will modify it in next beta. Thanks. Peter
DBG21060912	NEW Fixing	S2:Minor	[Monitor_Interface View][DV8 1.0.0.36]After disconnecting, the connected MAC will not be updated.

DBG21060913	NEW	Fixing	S2:Minor	[Monitor_Interface View][DV8 1.0.0.36]No connected interface name display.
DBG21060915	NEW	Fixing	S2:Minor	[Monitor_Interface View][DV8 1.0.0.36]No connected MAC addresses.
DBG21061079	NEW	Fixing	S2:Minor	[Monitor_LACP][1.0.0.36]No LACP links display at connection view/topology map.

Test Items

+	ID	Run	Status	Test Description	Bug ID
+	**DKP2103024** -- TSD1_Switch_D-View8				
+	0001	L	P	D-View 8 installation for WinOS	
+	0002	L	P	D-View 8 installation for Linux	
+	0003	L	P	MongoDB installation	
+	0004	L	P	D-View8 Dashboard - Overview - Devices/Alarms	
+	0005	L	F	D-View8 Dashboard - Overview - Devices Statistics Summary Result: the device statistics for Month and Quarter always be zero?	
+	0006	L	P	D-View8 Dashboard - Overview - Devices Type Statistics	
+	0007	L	P	D-View8 Dashboard - Overview - Alarm Statistics	
+	0008	L	P	D-View8 Dashboard - Overview - Architecture	
+	0009	L	P	D-View8 Dashboard - Switch- Devices/Alarms	
+	0010	L	P	D-View8 Dashboard - Switch - Alarm Statistics	
+	0011	L	P	D-View8 Dashboard - Switch - Running Status	
+	0012	L	P	D-View8 Dashboard - Switch - Temperature Statistics	
+	0013	L	P	D-View8 Dashboard - Switch - Top 10 Wired Throughput (RX/TX)	
+	0014	L	P	D-View8 Dashboard - Switch - Top 10 Memory Utilization	
+	0015	L	P	D-View8 Dashboard - Overview - Top 10 CPU Utilization	
+	0015	L	P	D-View8 Dashboard - Switch - Top 10 CPU Utilization	
+	0016	L	P	D-View8 Dashboard - Overview - Top 10 Response Time	
+	0016	L	P	D-View8 Dashboard - Switch - Top 10 Response Time	
+	0017	L	P	D-View8 Dashboard - Host- Devices/Alarms	
+	0018	L	P	D-View8 Dashboard - Host - Alarm Statistics	
+	0019	L	P	D-View8 Dashboard - Host - Running Status	
+	0020	L	P	D-View8 Dashboard - Host - Top 10 CPU Utilization	
+	0021	L	P	D-View8 Dashboard - Host - Top 10 Memory Utilization	
+	0022	L	P	D-View8 Dashboard - Host - Top 10 Most Installed Applications	
+	0023	L	P	D-View8 Dashboard - Host -Top 10 Volumes with Most Disk Usage	
+	0024	L	P	D-View8 Dashboard - Host - Top 10 Response Time	
+	0025	L	P	D-View8 Dashboard - Host - Top 10 Volumes with Least Disk Usage	
+	0026	L	P	D-View8 Dashboard - sFlow- Devices/Alarms	
+	0027	L	P	D-View8 Dashboard - sFlow - Top 10 Endpoints	
+	0028	L	P	D-View8 Dashboard - sFlow - Recent Alarms Statistics	
+	0029	L	P	D-View8 Dashboard - sFlow - Top 10 Applications	
+	0030	L	P	D-View8 Dashboard - sFlow - Top 10 QoS	
+	0031	L	P	D-View8 Dashboard - sFlow - Top 10 Conversations	
+	0032	L	P	D-View8 Dashboard - PoE- Devices/Alarms	
+	0033	L	P	D-View8 Dashboard - PoE - Alarm Statistics	
+	0034	L	F	D-View8 Dashboard - PoE - Running Status Summary Result: will improve on next version.	
+	0035	L	P	D-View8 Dashboard - PoE - Top 10 PSEs by Current PD Count	
+	0036	L	P	D-View8 Dashboard - PoE - Top 10 Ports by Current Flow	
+	0037	L	P	D-View8 Dashboard - PoE - Top 10 Ports by Power Consumption	
+	0038	L	P	D-View8 Dashboard - PoE - Top 10 Devices by Power Consumption	
+	0039	L	P	D-View8 Dashboard - PoE - Top 10 Response Time	
+	0040	L	P	D-View8 Dashboard - Customized Dashboard - Create	
+	0041	L	P	D-View8 Dashboard - Customized Dashboard - Edit	
+	0042	L	P	D-View8 Dashboard - Customized Dashboard - Delete	
+	0043	L	P	D-View8 Dashboard - Customized Dashboard - Refresh	
+	0044	L	P	D-View8 Dashboard - Customized Dashboard - Add Widget	
+	0045	L	P	D-View8 Dashboard - Customized Dashboard - Add Widget/Select Device	
+	0046	L	P	D-View8 Dashboard - Customized Dashboard - Delete Widget	
+	0047	L	P	D-View8 Dashboard - Customized Dashboard - Delete Graphics	

+	0048	L	P	D-View8 Dashboard - Customized Dashboard - Add Graphics
+	0049	L	P	D-View8 Dashboard - Customized Dashboard - Refresh Graphics
+	0050	L	P	D-View8 Dashboard - Customized Dashboard - Edit Graphics Title
+	0051	L	P	D-View8 Dashboard - Customized Dashboard - Apply to Home
+	**DKP2103025** -- TSD1_Switch_D-View8_Monitor			
+	0001	L	P	D-View8 Monitoring - Network Discovery - Add Network - Basic Information - Site / Network
+	0002	L	P	D-View8 Monitoring - Network Discovery - Add Network - Probe Mode
+	0003	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - IP Input Rule
+	0003	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range 1
+	0004	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - IP Range Input Rule
+	0004	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range 2
+	0005	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - Subnet Input Rule
+	0005	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range 3
+	0006	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - Multiple IP Type
+	0006	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range 4
+	0007	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range 5
+	0007	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range Delete
+	0008	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - Selected SNMP Credentials
+	0008	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - SNMP Credentials 1
+	0009	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - Highest Version Of The Correct SNMP Credential
+	0009	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - SNMP Credentials 2
+	0010	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - Prioritize the use of correct credential
+	0010	L	P	D-View8 Monitoring - Network Discovery - Add Network - Discovery Range - SNMP Credentials 3
+	0011	L	P	D-View8 Monitoring - Network Discovery - Add Network - Schedule - One Time
+	0012	L	P	D-View8 Monitoring - Network Discovery - Add Network - Schedule - Recurrent
+	0013	L	P	D-View8 Monitoring - Network Discovery - Add Network - Basic Information - Auto-Managed Enable
+	0014	L	P	D-View8 Monitoring - Network Discovery - Add Network - Basic Information - Auto-Managed Disable
+	0015	L	P	D-View8 Monitoring - Network Discovery - Add Network - Basic Information - Auto-Managed for MAC conflict
+	0016	L	P	D-View8 Monitoring - Network Discovery - Add Network - Basic Information - Auto-Managed for Stacking
+	0017	L	P	D-View8 Monitoring - Network Discovery - Add Network - Basic Information - Pingable devices
+	0018	L	P	D-View8 Monitoring - Network Discovery - Edit Network - Display
+	0019	L	P	D-View8 Monitoring - Network Discovery - Edit Network - Required rules
+	0020	L	P	D-View8 Monitoring - Network Discovery - Edit Network - Uniqueness verification
+	0021	L	P	D-View8 Monitoring - Network Discovery - Edit Network
+	0022	L	P	D-View8 Monitoring - Network Discovery - Discovery - Rediscover the Network
+	0023	L	P	D-View8 Monitoring - Network Discovery - Network Information
+	0024	L	P	D-View8 Monitoring - Network Discovery - Delete Network
+	0025	L	P	D-View8 Monitoring - Network Discovery - Search
+	0026	L	P	D-View8 Monitoring - Device View - All
+	0027	L	P	D-View8 Monitoring - Device View - All - Refresh
+	0028	L	P	D-View8 Monitoring - Device View - All - Export
+	0029	L	P	D-View8 Monitoring - Device View - All - Search
+	0030	L	P	D-View8 Monitoring - Device View - All - Only Pingable devices
+	0031	L	P	D-View8 Monitoring - Device View - Managed
+	0032	L	P	D-View8 Monitoring - Device View - Managed - Refresh
+	0033	L	P	D-View8 Monitoring - Device View - Managed - Check

+	0034	L	P	D-View8 Monitoring - Device View - Managed - Export
+	0035	L	P	D-View8 Monitoring - Device View - Managed - Search
+	0036	L	P	D-View8 Monitoring - Device View - Managed - Unmanage/Ignore
+	0037	L	P	D-View8 Monitoring - Device View - Managed - Device Type
+	0038	L	P	D-View8 Monitoring - Device View - Unmanaged
+	0039	L	P	D-View8 Monitoring - Device View - Unmanaged - Refresh
+	0040	L	P	D-View8 Monitoring - Device View - Unmanaged - Search
+	0041	L	P	D-View8 Monitoring - Device View - Unmanaged - Manage/Ignore
+	0042	L	P	D-View8 Monitoring - Device View - Ignored
+	0043	L	P	D-View8 Monitoring - Device View - Ignored - Refresh
+	0044	L	P	D-View8 Monitoring - Device View - Ignored - Search
+	0045	L	P	D-View8 Monitoring - Device View - Ignored - Delete
+	0046	L	P	D-View8 Monitoring - Device View - Conflicted
+	0047	L	P	D-View8 Monitoring - Device View - Conflicted - Refresh
+	0048	L	P	D-View8 Monitoring - Device View - Conflicted - Search
+	0049	L	P	D-View8 Monitoring - Device View - Conflicted - Delete
+	0050	L	P	D-View8 Monitoring - Device View - Switch Device Detail
+	0051	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - Device Information
+	0052	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - Performance Information
+	0053	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - Online (Availability)
+	0054	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - SNMP Protocol Preferences
+	0055	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - Edit SNMP Protocol Preferences
+	0056	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - SNMP Protocol Preferences Test
+	0057	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - SNMP Protocol Preferences Reset
+	0058	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - Edit Additional Information
+	0059	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Summary - LACP Working Status
+	0060	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Port - Overview
+	0061	L	F	D-View8 Monitoring - Device View - Switch Device Detail - Port - Overview Operation Summary Result: [Monitor][1.0.0.36]the charts of "Interface Monitoring Results" dose not show correct port data.
+	0062	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Port - Port List
+	0063	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Port - Port List - Port Operation
+	0064	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Port - Port List - Ports Operation
+	0065	L	F	D-View8 Monitoring - Device View - Switch Device Detail - Port - Comparison - Port Interface Monitoring Results Summary Result: [Monitor][1.0.0.36]the charts of "Interface Monitoring Results" dose not show correct port data.
+	0066	L	F	D-View8 Monitoring - Device View - Switch Device Detail - Port - Comparison - Interface Monitoring Results of Multiple Switches Summary Result: [Monitor][1.0.0.36]the charts of "Interface Monitoring Results" dose not show correct port data.
+	0067	L	F	D-View8 Monitoring - Device View - Switch Device Detail - Port - Comparison - Interface Monitoring Results of Selected Monitor Charts Summary Result: [Monitor][1.0.0.36]the charts of "Interface Monitoring Results" dose not show correct port data.
+	0068	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Port - Alarm Settings
+	0069	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Refresh
+	0070	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Reboot
+	0071	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Monitor - System Monitor

+	0072	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Monitor - Customized Monitor
+	0072	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Monitor - Customized System Monitor
+	0073	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Monitor - Monitoring Settings
+	0074	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Monitor Views - Network Table
+	0075	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Monitor Views - Topology Map
+	0076	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Alarm - Active Alarms
+	0077	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Alarm - Active Alarms Operation
+	0078	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Alarm - Active Alarm settings
+	0079	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Alarm - Historical Alarms
+	0080	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Alarm - Historical Alarms Operation
+	0081	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Trap Log Data list
+	0082	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Trap Log Search
+	0083	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Trap Log Sort
+	0084	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Trap Log Refresh
+	0085	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Translation set
+	0086	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Syslog Data list
+	0087	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Syslog Search
+	0088	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Syslog Sort
+	0089	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Trap & Syslog - Syslog Refresh
+	0090	L	P	D-View8 Monitoring - Device View - Switch Device Detail - PoE - PoE Power Supply Summary
+	0091	L	P	D-View8 Monitoring - Device View - Switch Device Detail - PoE - PoE Port List
+	0092	L	P	D-View8 Monitoring - Device View - Switch Device Detail - PoE - Edit PoE Plan
+	0093	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - Basic configuration
+	0094	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - Quick configuration
+	0095	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - advanced configuration
+	0096	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - Firmware Upgrade
+	0097	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - Configuration File Backup
+	0098	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - Configuration File Restore
+	0099	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - Task
+	0100	L	P	D-View8 Monitoring - Device View - Switch Device Detail - Management - sFlow
+	0101	L	P	D-View8 Monitoring - Interface View list
+	0102	L	P	D-View8 Monitoring - Interface View - System name and IP
+	0103	L	P	D-View8 Monitoring - Interface View - Model Name/Network/Update Time
+	0104	L	F	D-View8 Monitoring - Interface View - Interface related information Summary Result: [Monitor_Interface View] 1)After disconnecting, the connected MAC will not be updated. 2)No connected interface name display. 3)No connected MAC addresses.
+	0105	L	P	D-View8 Monitoring - Interface View - VLAN related information

+	0106	L	P	D-View8 Monitoring - Interface View - Search	
+	0107	L	P	D-View8 Monitoring - Interface View - Sort	
+	0108	L	P	D-View8 Monitoring - Interface View - Refresh	
+	0109	L	P	D-View8 Monitoring - Interface View - Export	
+	0110	L	P	D-View8 Monitoring - Interface View - Pagination	
+	0111	L	P	D-View8 Monitoring - Connection View list	
+	0112	L	P	D-View8 Monitoring - Connection View - Operation	
+	0113	L	P	D-View8 Monitoring - Connection View - Refresh	
+	0114	L	P	D-View8 Monitoring - Connection View - Export	
+	0115	L	P	D-View8 Monitoring - Connection View - Search	
+	0116	L	P	D-View8 Monitoring - Connection View - Summary interface display	
+	0117	L	P	D-View8 Monitoring - Connection View - Summary interface operation	
+	0118	L	P	D-View8 Monitoring - Connection View - Monitor interface display	
+	0119	L	P	D-View8 Monitoring - Connection View - Alarm interface display	
+	0120	L	P	D-View8 Monitoring - Connection View - Alarm interface operation	
+	0121	L	P	D-View8 Monitoring - Connection View - Alarm interface refresh	
+	0122	L	P	D-View8 Monitoring - Connection View - Alarm interface search	
+	0123	L	P	D-View8 Monitoring - Connection View - Alarm message confirmation	
+	0124	L	P	D-View8 Monitoring - Rack View - Add Group	
+	0125	L	P	D-View8 Monitoring - Rack View - Edit Group	
+	0126	L	P	D-View8 Monitoring - Rack View - Search Group	
+	0127	L	P	D-View8 Monitoring - Rack View - Delete Group	
+	0128	L	P	D-View8 Monitoring - Rack View - Add Rack	
+	0129	L	P	D-View8 Monitoring - Rack View - Add/Delete Units	
+	0130	L	P	D-View8 Monitoring - Rack View - View Units	
+	0131	L	P	D-View8 Monitoring - Rack View - Edit Rack	
+	0132	L	P	D-View8 Monitoring - Rack View - Delete Rack	
+	0133	L	P	D-View8 Monitoring - Rack View - Refresh	
+	0134	L	P	D-View8 Monitoring - Rack View - Rack operation	
+	0135	L	P	D-View8 Monitoring - Device Group - Add	
+	0136	L	P	D-View8 Monitoring - Device Group - Edit	
+	0137	L	P	D-View8 Monitoring - Device Group - Search	
+	0138	L	P	D-View8 Monitoring - Device Group - Refresh	
+	0139	L	P	D-View8 Monitoring - Device Group - Delete	
+	0140	L	P	D-View8 Monitoring - Topology Map - System Topology - Save	
+	0141	L	P	D-View8 Monitoring - Topology Map - System Topology - Refresh	
+	0142	L	P	D-View8 Monitoring - Topology Map - System Topology - Link Edit	
+	0143	L	N	D-View8 Monitoring - Topology Map - System Topology - Huge topology	
+	0144	L	P	D-View8 Monitoring - Topology Map - System Topology	
+	0145	L	P	D-View8 Monitoring - Topology Map - System Topology - Alarm ICON	
+	0146	L	P	D-View8 Monitoring - Topology Map - System Topology - Search	
+	0147	L	P	D-View8 Monitoring - Topology Map - System Topology - Zoom	
+	0148	L	P	D-View8 Monitoring - Topology Map - System Topology - Topological Legend	
+	0149	L	P	D-View8 Monitoring - Topology Map - System Topology - Device List	
+	0150	L	P	D-View8 Monitoring - Topology Map - System Topology - Link List	
+	0151	L	P	D-View8 Monitoring - Topology Map - System Topology - Batch Select Nodes	
+	0152	L	P	D-View8 Monitoring - Topology Map - System Topology - Network Overview	
+	0153	L	P	D-View8 Monitoring - Topology Map - System Topology - Topology Settings	
+	0154	L	P	D-View8 Monitoring - Topology Map - System Topology - Add Background Image	
+	0155	L	P	D-View8 Monitoring - Topology Map - System Topology - Rediscover	
+	0156	L	P	D-View8 Monitoring - Topology Map - System Topology - Export	
+	0157	L	P	D-View8 Monitoring - Topology Map - Search	
+	0158	L	P	D-View8 Monitoring - Topology Map - System Topology - Device Info	
+	0159	L	P	D-View8 Monitoring - Topology Map - System Topology - Link Info	
+	0160	L	F	D-View8 Monitoring - Topology Map - System Topology - LACP/Multiple links Summary Result: [Monitor_LACP][1.0.0.36]No LACP links display at connection view/topology map.	
+	0161	L	P	D-View8 Monitoring - Topology Map - System Topology - VLAN Topology	
+	0162	L	P	D-View8 Monitoring - Topology Map - System Topology - VLAN Topology Save	
+	0163	L	P	D-View8 Monitoring - Topology Map - Create Customized Topology	
+	0164	L	P	D-View8 Monitoring - Topology Map - Edit Customized Topology	
+	0165	L	P	D-View8 Monitoring - Topology Map - Delete Customized Topology	

+	0167	L	P	D-View8 Monitoring - Topology Map - Customized Topology - Select Devices
+	0168	L	P	D-View8 Monitoring - Topology Map - Customized Topology - Refresh/Export/Topology Settings/Link Edit/Add Background Image/Save
+	0169	L	P	D-View8 Monitoring - Topology Map - Topology Synchronization
+	0170	L	P	D-View8 Monitoring - sFlow Analyzer - sFlow Agents
+	0171	L	P	D-View8 Monitoring - sFlow Analyzer - Source default data display
+	0172	L	P	D-View8 Monitoring - sFlow Analyzer - Source data check
+	0173	L	P	D-View8 Monitoring - sFlow Analyzer - Source - Data display in different time ranges
+	0174	L	P	D-View8 Monitoring - sFlow Analyzer - Source - Data display of different sFlow directions
+	0175	L	P	D-View8 Monitoring - sFlow Analyzer - Display source data in different forms
+	0176	L	P	D-View8 Monitoring - sFlow Analyzer - Source - Page Jump
+	0177	L	P	D-View8 Monitoring - sFlow Analyzer - Source - Export
+	0178	L	P	D-View8 Monitoring - sFlow Analyzer - Destination default data display
+	0179	L	P	D-View8 Monitoring - sFlow Analyzer - Destination data check
+	0180	L	P	D-View8 Monitoring - sFlow Analyzer - Destination - Data display in different time ranges
+	0181	L	P	D-View8 Monitoring - sFlow Analyzer - Display destination data in different forms
+	0182	L	P	D-View8 Monitoring - sFlow Analyzer - Destination - Page jump
+	0183	L	P	D-View8 Monitoring - sFlow Analyzer - Destination - Export
+	0184	L	P	D-View8 Monitoring - sFlow Analyzer - QoS - Page jump
+	0185	L	P	D-View8 Monitoring - sFlow Analyzer - QoS data check
+	0186	L	P	D-View8 Monitoring - sFlow Analyzer - QoS - Export
+	0187	L	P	D-View8 Monitoring - sFlow Analyzer - Application default data display
+	0188	L	P	D-View8 Monitoring - sFlow Analyzer - Application data check
+	0189	L	P	D-View8 Monitoring - sFlow Analyzer - Application - Add Mapping
+	0190	L	P	D-View8 Monitoring - sFlow Analyzer - Conversation default data display
+	0191	L	P	D-View8 Monitoring - sFlow Analyzer - Conversation - Search
+	0192	L	P	D-View8 Monitoring - sFlow Analyzer - Conversation detail
+	**DKP2103026** -- TSD1_Switch_D-View8_Configuration			
+	0001	L	P	D-View 8_Quick Configuration_Configuration Category Display
+	0002	L	P	D-View 8_Quick Configuration_Add Quick Configuration Task
+	0003	L	P	D-View 8_Quick Configuration_CLI protocol configuration item issued
+	0003	L	P	D-View 8_Quick Configuration_Distribute CLI protocol configuration
+	0004	L	P	D-View 8_Quick Configuration_New task interface test
+	0005	L	P	D-View 8_Quick Configuration_Refresh Task interface
+	0006	L	P	D-View 8_Quick Configuration_Page jump
+	0006	L	P	D-View 8_Quick Configuration_The page jumps
+	0007	L	P	D-View 8_Advanced Configuration_Add Profile
+	0008	L	P	D-View 8_Advanced Configuration_Profile name repeated
+	0009	L	P	D-View 8_Advanced Configuration_Distribute profile configuration
+	0009	L	P	D-View 8_Advanced Configuration_The profele configuration issued
+	0010	L	P	D-View 8_Advanced Configuration_Copy Profile
+	0011	L	P	D-View 8_Advanced Configuration_Edit profele
+	0011	L	P	D-View 8_Advanced Configuration_Edit profile
+	0012	L	P	D-View 8_Advanced Configuration_Remove profele
+	0012	L	P	D-View 8_Advanced Configuration_Remove profile
+	0013	L	P	D-View 8_Advanced Configuration_Page jump
+	0013	L	P	D-View 8_Advanced Configuration_The page jumps
+	0014	L	P	D-View 8_Advanced Configuration_List data filtering
+	0015	L	P	D-View 8_Backup_Backup list display
+	0015	L	P	D-View 8_Backup_Backup list displayed
+	0016	L	P	D-View 8_Backup_Backup list action
+	0016	L	P	D-View 8_Backup_Backup list operation
+	0017	L	P	D-View 8_Backup_Backup list refresh
+	0017	L	P	D-View 8_Backup_Backup list refreshed
+	0018	L	P	D-View 8_Backup_Backup list query
+	0019	L	P	D-View 8_Backup_Backup feature verification
+	0019	L	P	D-View 8_Backup_Backup function verification
+	0020	L	P	D-View 8_Restore_Restore list display
+	0020	L	P	D-View 8_Restore_Restore list displayed

+	0021	L	P	D-View 8_Restore_Restore list action
+	0021	L	P	D-View 8_Restore_Restore list operation
+	0022	L	P	D-View 8_Restore_Backup list refresh
+	0022	L	P	D-View 8_Restore_Restore list refreshed
+	0023	L	P	D-View 8_Restore_Restore list query
+	0024	L	P	D-View 8_Restore_Restore feature verification
+	0024	L	P	D-View 8_Restore_Restore function verification
+	0025	L	P	D-View 8_File Management_File Management list display
+	0025	L	P	D-View 8_File Management_File Management list displayed
+	0026	L	P	D-View 8_File Management_File Management list action
+	0026	L	P	D-View 8_File Management_File Management list operations
+	0027	L	P	D-View 8_File Management_File Management list refresh
+	0028	L	P	D-View 8_File Management_File Management list query
+	0029	L	P	D-View 8_File Management_File Management Upload feature verification
+	0029	L	P	D-View 8_File Management_File Management Upload function verification
+	0030	L	P	D-View 8_File Management_File Management batch delete function verification
+	0030	L	P	D-View 8_File Management_File Management Bulk Delete feature verification
+	0031	L	P	D-View 8_File Management_File Management file comparison function verification
+	0031	L	P	D-View 8_File Management_File Management file-to-function verification
+	0032	L	P	D-View 8_Task Management_Current Task list
+	0032	L	P	D-View 8_Task Management_Current Task list display
+	0033	L	P	D-View 8_Task Management_Current Task list action
+	0033	L	P	D-View 8_Task Management_Current Task list operation
+	0034	L	P	D-View 8_Task Management_Current Task list refresh
+	0034	L	P	D-View 8_Task Management_Refresh Current Task list
+	0035	L	P	D-View 8_Task Management_Current Task list query
+	0036	L	P	D-View 8_Task Management_Historical Task list display
+	0036	L	P	D-View 8_Task Management_Previous Task list displayed
+	0037	L	P	D-View 8_Task Management_Historical Task list operation
+	0037	L	P	D-View 8_Task Management_Previous Task list operation
+	0038	L	P	D-View 8_Task Management_Historical Task list refresh
+	0038	L	P	D-View 8_Task Management_Refreshes Previous Task list
+	0039	L	P	D-View 8_Task Management_Historical Task list query
+	0039	L	P	D-View 8_Task Management_Previous Task list query
+	0040	L	P	D-View 8_Fireware Management_Resource tree data
+	0041	L	P	D-View 8_Fireware Management_Resource tree search
+	0042	L	P	D-View 8_Fireware Management_Resource tree full selection/reverse selection
+	0042	L	P	D-View 8_Fireware Management_Resource tree selection
+	0043	L	P	D-View 8_Fireware Management_Resource tree refresh
+	0044	L	P	D-View 8_Fireware Management_Device group list
+	0045	L	P	D-View 8_Fireware Management_Firmware file is uploaded and shared
+	0045	L	P	D-View 8_Fireware Management_Upload and share firmware files
+	0046	L	P	D-View 8_Fireware Management_Create firmware upgrade task
+	0047	L	P	D-View 8_Fireware Management_Edit firmware upgrade task
+	0047	L	P	D-View 8_Fireware Management_Edit the firmware upgrade task
+	0048	L	P	D-View 8_Fireware Management_Delete firmware upgrade task
+	0048	L	P	D-View 8_Fireware Management_Remove the firmware upgrade task
+	0049	L	P	D-View 8_Fireware Management_Restart device operation
+	0049	L	P	D-View 8_Fireware Management_Restart the device operation
+	0050	L	P	D-View 8_Fireware Management_Correct device list data
+	0050	L	P	D-View 8_Fireware Management_Device list data correct
+	0051	L	P	D-View 8_Fireware Management_Refresh of the list of devices
+	0051	L	P	D-View 8_Fireware Management_Refresh the device list
+	0052	L	P	D-View 8_Fireware Management_Sort of device list data
+	0052	L	P	D-View 8_Fireware Management_Sorting of device list data
+	0053	L	P	D-View 8_Fireware Management_Column queries and advanced query features
+	0053	L	P	D-View 8_Fireware Management_Column query and advanced query function test
+	**DKP2104004** -- TSD1_Switch_D-View8_Tools			
+	0001	L	P	D-View 8_Tools_Users login page Tools
+	0002	L	P	D-View 8_Tools_MIB Browser_MIB Compiler entry
+	0003	L	P	D-View 8_Tools_MIB Browser_MIB Tree display check

+	0004	L	P	D-View 8_Tools_MIB Browser_MIB Tree search verification
+	0005	L	P	D-View 8_Tools_MIB Browser_MIB Modules display check
+	0006	L	P	D-View 8_Tools_MIB Browser_MIB Modules search verification
+	0007	L	P	D-View 8_Tools_MIB Browser_Contact function verification
+	0008	L	P	D-View 8_Tools_MIB Browser_Contact and view properties check
+	0009	L	P	D-View 8_Tools_MIB Browser_SNMP Operations operation verification_MIB Tree and MIB Modules test
+	0010	L	P	D-View 8_Tools_MIB Browser_SNMP Operations operation verification_OID and Operations test
+	0011	L	P	D-View 8_Tools_MIB Browser_SNMP Protocol Preference configuration verification
+	0012	L	P	D-View 8_Tools_MIB Browser_Operation Verification_Get/Get Next/Get Batch/Walk
+	0013	L	P	D-View 8_Tools_MIB Browser_Operation Verification_Table view
+	0014	L	P	D-View 8_Tools_MIB Browser_Operation Verification_Instance View
+	0015	L	P	D-View 8_Tools_MIB Browser_Operation Verification_Set
+	0016	L	P	D-View 8_Tools_MIB Compiler_MIB check
+	0017	L	P	D-View 8_Tools_MIB Compiler_Header Sorting Functional verification
+	0018	L	P	D-View 8_Tools_MIB Compiler_Module identity search function verification
+	0019	L	P	D-View 8_Tools_MIB Compiler_Compiled Modules delete and refresh functions verification
+	0020	L	P	D-View 8_Tools_MIB Compiler_Upload not Compiled single file
+	0021	L	P	D-View 8_Tools_MIB Compiler_Upload not Compiled folder
+	0022	L	P	D-View 8_Tools_MIB Compiler_Information check of uploaded MIB file
+	0023	L	P	D-View 8_Tools_MIB Compiler_Compilation success rate check
+	0024	L	P	D-View 8_Tools_MIB Compiler_Not Compiled Modules delete and refresh functions verification
+	0025	L	P	D-View 8_Tools_MIB Compiler_Compiled and Not Compiled tables Functional verification
+	0026	L	P	D-View 8_Tools_ICMP Ping_Verify the basic functions
+	0027	L	P	D-View 8_Tools_ICMP Ping_Functional verification of Ping IPv6 address
+	0028	L	P	D-View 8_Tools_ICMP Ping_Ping Result data accuracy check
+	0029	L	P	D-View 8_Tools_ICMP Ping_Modification and verification of Ping Time
+	0030	L	P	D-View 8_Tools_ICMP Ping_Inspection of illegal IP input
+	0031	L	P	D-View 8_Tools_ICMP Ping_Functional verification of automatic filling device information
+	0032	L	P	D-View 8_Tools_SNMP Test_Verify the basic functions of SNMP Test
+	0033	L	P	D-View 8_Tools_SNMP Test_Modification and verification of Ping Time
+	0034	L	P	D-View 8_Tools_SNMP Test_Modification and verification of SNMP related parameters
+	0035	L	P	D-View 8_Tools_SNMP Test_Functional Verification of IPv6 Address of SNMP Test Equipment
+	0036	L	P	D-View 8_Tools_SNMP Test_Inspection of illegal IP input
+	0037	L	P	D-View 8_Tools_SNMP Test_Functional verification with automatic filling of device information
+	0038	L	P	D-View 8_Tools_Trace Route_Verify the basic functions of Trace Route
+	0039	L	P	D-View 8_Tools_Trace Route_Modification and verification of Maximum Hops
+	0040	L	P	D-View 8_Tools_Trace Route_Functional verification of Trace Route device IPv6 address
+	0041	L	P	D-View 8_Tools_Trace Route_Inspection of illegal IP input
+	0042	L	P	D-View 8_Tools_Trace Route_Functional verification with automatic filling of device information
+	0043	L	P	D-View 8_Tools_CLI_Verify the basic functions of Telnet and SSH
+	0044	L	P	D-View 8_Tools_CLI_Functional verification of Clear
+	0045	L	P	D-View 8_Tools_CLI_Functional verification of Disconnect
+	0046	L	P	D-View 8_Tools_CLI_Check for abnormal login
+	0047	L	P	D-View 8_Tools_CLI_Multi-Connection function verification
+	0048	L	P	D-View 8_Tools_CLI_Functional verification of IPv6 addresses of Telnet/SSH devices
+	0049	L	P	D-View 8_Tools_CLI_CLI routine operation and return function verification
+	0050	L	P	D-View 8_Tools_File Comparison_Basic function verification of File Comparison
+	0051	L	P	D-View 8_Tools_File Comparison_Model name and configuration file selection check
+	0052	L	P	D-View 8_Tools_File Comparison_Functional verification of Lock/UnLock Scrolling
+	0053	L	P	D-View 8_Tools_File Comparison_Copy to right/left functional verification

+	0054	L	P	D-View 8_Tools_File Comparison_Functional verification of Reload File
+	0055	L	P	D-View 8_Tools_File Comparison_Functional verification of Save As
+	0056	L	P	D-View 8_Tools_File Comparison_Functional verification of Restore To Device
+	**DKP2104007** -- TSD1_Switch_D-View8_Alarm			
+	0001	L	P	D-View8 Alarm - Active Alarms
+	0002	L	P	D-View8 Alarm - Historical Alarms
+	0003	L	P	D-View8 Alarm - Alarm Icon Level Filter
+	0004	L	P	D-View8 Trap and Syslog - Trap
+	0005	L	P	D-View8 Trap and Syslog - Syslog
+	0006	L	P	D-View8 Trap Editor - Add/Delete
+	0007	L	P	D-View8 Trap Editor - Trap OID Duplicated Detected
+	0008	L	P	D-View8 Trap Editor - Filter
+	0009	L	P	D-View8 Monitor & Alarm Settings - Monitor Setting - Display
+	0010	L	P	D-View8 Monitor & Alarm Settings - Monitor Setting - Edit
+	0011	L	P	D-View8 Monitor & Alarm Settings - Monitor Setting - Filter
+	0012	L	P	D-View8 Monitor & Alarm Settings - Monitor Setting - Port alarm setting
+	0013	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting - Add
+	0014	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting - Edit/Delete
+	0015	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting - Filter
+	0016	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting Trap - Add/Edit/Delete
+	0017	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting Syslog - Add/Edit/Delete
+	0018	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting sFlow - Add/Edit/Delete
+	0019	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting - Inhibition Schedule
+	0020	L	P	D-View8 Monitor & Alarm Settings - Alarm Setting Rule Definition- Add/Edit/Delete
+	0021	L	P	D-View8 - Notification Center - Add (Monitor)
+	0022	L	P	D-View8 - Notification Center - Add (Trap)
+	0023	L	P	D-View8 - Notification Center - Add (Syslog)
+	0024	L	P	D-View8 - Notification Center - Add (Port)
+	0025	L	P	D-View8 - Notification Center - Notification type
+	0026	L	P	D-View8 - Notification Center - Notification type (Execute Script)
+	0027	L	P	D-View8 - Notification Center - Notification type (Execute Script with Alarm Handling)
+	0028	L	P	D-View8 - Notification Center - Notification type (modify)
+	0029	L	P	D-View8 - Notification Center - Sound Setting
+	0030	L	P	D-View8 - Notification Center - Search
+	0031	L	P	D-View8 - Notification Center - Notification Alarm Message Icon.
+	**DKP2106004** -- TSD1_Switch_D-View8_Reports			
+	0001	L	P	D-View 8_Reports_General Reports_Generate Device Health Reports functional verification
+	0002	L	P	D-View 8_Reports_General Reports_View Device Health Reports
+	0003	L	P	D-View 8_Reports_General Reports_Functional verification in the Reports Settings window
+	0004	L	P	D-View 8_Reports_General Reports_Modify Device Health Reports function verification
+	0005	L	P	D-View 8_Reports_General Reports_Export Device Health Reports function verification
+	0006	L	P	D-View 8_Reports_General Reports_Refresh Device Health Reports function verification
+	0007	L	P	D-View 8_Reports_General Reports_Save Device Health Reports function verification
+	0008	L	P	D-View 8_Reports_General Reports_Upgraded Device Health Reports to plan report function verification
+	0009	L	P	D-View 8_Reports_General Reports_Generate Trap Reports function verification
+	0010	L	P	D-View 8_Reports_General Reports_View Trap Reports
+	0011	L	P	D-View 8_Reports_General Reports_Modify Trap Reports function verification
+	0012	L	P	D-View 8_Reports_General Reports_Export Trap Reports function verification
+	0013	L	P	D-View 8_Reports_General Reports_Refresh Trap Reports function verification
+	0014	L	P	D-View 8_Reports_General Reports_Save Trap Reports function verification
+	0015	L	P	D-View 8_Reports_General Reports_Upgrade Trap Reports to plan report function verification
+	0016	L	P	D-View 8_Reports_General Reports_Generate Syslog Reports function verification

+	0017	L	P	D-View 8_Reports_General Reports_View Syslog Reports
+	0018	L	P	D-View 8_Reports_General Reports_Modify Syslog Reports function verification
+	0019	L	P	D-View 8_Reports_General Reports_Export Syslog Reports function verification
+	0020	L	P	D-View 8_Reports_General Reports_Refresh Syslog Reports function verification
+	0021	L	P	D-View 8_Reports_General Reports_Save Syslog Reports function verification
+	0022	L	P	D-View 8_Reports_General Reports_Upgrade Syslog Reports to plan report function verification
+	0023	L	P	D-View 8_Reports_General Reports_Generate Device Top N Reports function verification
+	0024	L	P	D-View 8_Reports_General Reports_View Device Top N Reports
+	0025	L	P	D-View 8_Reports_General Reports_Modify Device Top N Reports function verification
+	0026	L	P	D-View 8_Reports_General Reports_Export Device Top N Reports function verification
+	0027	L	P	D-View 8_Reports_General Reports_Refresh the Device Top N Reports function verification
+	0028	L	P	D-View 8_Reports_General Reports_Save Device Top N Reports function verification
+	0029	L	P	D-View 8_Reports_General Reports_Upgraded Device Top N Reports function verification
+	0030	L	P	D-View 8_Reports_General Reports_Generate Wired Traffic Reports functional verification
+	0031	L	P	D-View 8_Reports_General Reports_View Wired Traffic Reports
+	0032	L	P	D-View 8_Reports_General Reports_Modify the functional verification of Wired Traffic Reports
+	0033	L	P	D-View 8_Reports_General Reports_Export Wired Traffic Reports function verification
+	0034	L	P	D-View 8_Reports_General Reports_Refresh the functional verification of Wired Traffic Reports
+	0035	L	P	D-View 8_Reports_General Reports_Save Wired Traffic Reports function verification
+	0036	L	P	D-View 8_Reports_General Reports_Upgrade Wired Traffic Reports function verification
+	0037	L	P	D-View 8_Reports_General Reports_Generate Wired Top N Reports functional verification
+	0038	L	P	D-View 8_Reports_General Reports_View Wired Top N Reports
+	0039	L	P	D-View 8_Reports_General Reports_Modify Wired Top N Reports function verification
+	0040	L	P	D-View 8_Reports_General Reports_Export Wired Top N Reports function verification
+	0041	L	P	D-View 8_Reports_General Reports_Refresh the function verification of Wired Top N Reports
+	0042	L	P	D-View 8_Reports_General Reports_Save Wired Top N Reports functional verification
+	0043	L	P	D-View 8_Reports_General Reports_Upgrade Wired Top N Reports function verification
+	0044	L	P	D-View 8_Reports_General Reports_Generate Inventory Reports functional verification
+	0045	L	P	D-View 8_Reports_General Reports_Modify Inventory Reports function verification
+	0046	L	P	D-View 8_Reports_General Reports_Export Inventory Reports function verification
+	0047	L	P	D-View 8_Reports_General Reports_Refresh Inventory Reports function verification
+	0048	L	P	D-View 8_Reports_General Reports_Save Inventory Reports function verification
+	0049	L	P	D-View 8_Reports_General Reports_Upgrade Inventory Reports function verification
+	0050	L	P	D-View 8_Reports_Scheduled Reports_One Time type report list display
+	0051	L	P	D-View 8_Reports_Scheduled Reports_One Time type report operation
+	0052	L	P	D-View 8_Reports_Scheduled Reports_One Time type report search
+	0053	L	P	D-View 8_Reports_Scheduled Reports_One Time type report refresh
+	0054	L	P	D-View 8_Reports_Scheduled Reports_View the generated report
+	0055	L	P	D-View 8_Reports_Scheduled Reports_Recurrent type report list display
+	0056	L	P	D-View 8_Reports_Scheduled Reports_Recurrent type report operation
+	0057	L	P	D-View 8_Reports_Scheduled Reports_Recurrent type report search
+	0058	L	P	D-View 8_Reports_Scheduled Reports_Recurrent type report refresh

+	0059	L	P	D-View 8_Reports_Scheduled Reports_Recurrent type view the generated report
+	0060	L	P	D-View 8_Reports_Scheduled Reports_Verify the function of pause and start
+	0061	L	P	D-View 8_Reports_My Reports_My Reports list display
+	0062	L	P	D-View 8_Reports_My Reports_My Reports operation
+	0063	L	P	D-View 8_Reports_My Reports_My Reports search
+	0064	L	P	D-View 8_Reports_My Reports_My Reports refresh
+	0065	L	P	D-View 8_Reports_My Reports_View the generated report
+	0066	L	P	D-View 8_Reports_My Reports_Functional verification of the maximum number of Reports
+	**DKP2106012** -- TSD1_Switch_D-View8_System			
+	0001	L	P	D-View 8_System_Basic Settings_Organization editing function verification
+	0002	L	P	D-View 8_System_Basic Settings_Mail Server Settings editing function verification
+	0003	L	P	D-View 8_System_Basic Settings_Forward Trap list operation
+	0004	L	P	D-View 8_System_Basic Settings_Forward Trap function verification
+	0005	L	P	D-View 8_System_Basic Settings_Forward Syslog list operation
+	0006	L	P	D-View 8_System_Basic Settings_Forward Syslog function verification
+	0007	L	P	D-View 8_System_Basic Settings_REST API list operation
+	0008	L	P	D-View 8_System_Basic Settings_REST API list query
+	0009	L	P	D-View 8_System_Basic Settings_REST API function verification
+	0010	L	P	D-View 8_System_Basic Settings_SNMP Protocol Preference Add Voucher
+	0011	L	P	D-View 8_System_Basic Settings_SNMP Protocol Preference Edit/Delete
+	0012	L	P	D-View 8_System_Basic Settings_SNMP Protocol Preference Search/Refresh
+	0013	L	P	D-View 8_System_Basic Settings_Sflow Application Mapping Features Verification
+	0014	L	P	D-View 8_System_Basic Settings_Sflow IP Alias Mapping Features Verification
+	0015	L	P	D-View 8_System_Basic Settings_Sflow Mac Address Mapping Features Verification
+	0016	L	P	D-View 8_System_Basic Settings_Sflow DSCP Mapping Features Verification
+	0017	L	P	D-View 8_System_Basic Settings_Table Settings Modify Features Verification
+	0018	L	P	D-View 8_System_Basic Settings_Theme settings
+	0019	L	P	D-View 8_System_User Management_User adds functional verification
+	0020	L	P	D-View 8_System_User Management_User list Operation/Refresh
+	0021	L	P	D-View 8_System_User Management_User list query
+	0022	L	P	D-View 8_System_User Management_User function permission view
+	0023	L	P	D-View 8_System_User Management_AD Server list operation
+	0024	L	P	D-View 8_System_User Management_AD Server list refresh
+	0025	L	P	D-View 8_System_User Management_AD Server function verification
+	0026	L	P	D-View 8_System_User Management_RADIUS Server function verification
+	0027	L	P	D-View 8_System_Scheduling_Recurrent Schedule List_Frequency type schedule new function verification
+	0028	L	P	D-View 8_System_Scheduling_Recurrent Schedule List_Verify Edit/Delete the frequency type schedule function
+	0029	L	P	D-View 8_System_Scheduling_Time Range Schedule List_Verify that the range type schedule function is added
+	0030	L	P	D-View 8_System_Scheduling_Time Range Schedule List_Verify Edit/Delete range type schedule function
+	0031	L	P	D-View 8_System_Scheduling_Time Range Schedule List_Verify the column query or advanced query function verification
+	0032	L	P	D-View 8_System_Server Management_Probe_Probe basic information check
+	0033	L	P	D-View 8_System_Server Management_Probe_Verify the search function of Advanced Query
+	0034	L	P	D-View 8_System_Server Management_Probe_Verify refresh function
+	0035	L	P	D-View 8_System_Server Management_Probe_Verify Probe Export function
+	0036	L	P	D-View 8_System_Server Management_Probe_Edit Probe Name and Location function verification
+	0037	L	P	D-View 8_System_Server Management_Probe_Report view function verification
+	0038	L	P	D-View 8_System_Server Management_Probe_Basic function verification of Report Export
+	0039	L	P	D-View 8_System_Server Management_Core Server_Core Server basic information check
+	0040	L	P	D-View 8_System_Server Management_Core Server_Verify the search function of Advanced Query
+	0041	L	P	D-View 8_System_Server Management_Core Server_Verify CoreServer refresh function

+	0042	L	P	D-View 8_System_Server Management_Core Server_Verify CoreServer Export function
+	0043	L	P	D-View 8_System_Server Management_Core Server_Edit Server Name and Location function verification
+	0044	L	P	D-View 8_System_Server Management_Core Server_Report view function verification
+	0045	L	P	D-View 8_System_Server Management_Core Server_Basic function verification of Report Export
+	0046	L	P	D-View 8_System_Server Management_Web Server_Web Server basic information check and verification
+	0047	L	P	D-View 8_System_Server Management_Web Server_Verify the search function of Advanced Query
+	0048	L	P	D-View 8_System_Server Management_Web Server_Verify Web Server refresh function
+	0049	L	P	D-View 8_System_Server Management_Web Server_Verify Web Server Export function
+	0050	L	P	D-View 8_System_Server Management_Web Server_Edit Server Name and Location function verification
+	0051	L	P	D-View 8_System_Server Management_Web Server_Report view function verification
+	0052	L	P	D-View 8_System_D-View 8 Log_User Operation_Log Time and Terminal Type sorting function verification
+	0053	L	P	D-View 8_System_D-View 8 Log_User Operation_User and Object Entity filter function verification
+	0054	L	P	D-View 8_System_D-View 8 Log_User Operation_Validation of search function in advanced query window
+	0055	L	P	D-View 8_System_D-View 8 Log_User Operation_Clear filter conditions function verification
+	0056	L	P	D-View 8_System_D-View 8 Log_User Operation_Verify refresh function
+	0057	L	P	D-View 8_System_D-View 8 Log_System Log_View the system log
+	0058	L	P	D-View 8_System_D-View 8 Log_System Log_System Log sorting function verification
+	0059	L	P	D-View 8_System_D-View 8 Log_System Log_Validation of search function in advanced query window
+	0060	L	P	D-View 8_System_D-View 8 Log_Device Maintenance_View corresponding Device Config Log
+	0061	L	P	D-View 8_System_D-View 8 Log_Device Maintenance_Device Maintenance Log sorting function verification
+	0062	L	P	D-View 8_System_D-View 8 Log_Device Maintenance_Validation of search function in advanced query window
+	0063	L	P	D-View 8_System_D-View 7 Upgrade_Verify Database Migration connection function
+	0064	L	P	D-View 8_System_D-View 7 Upgrade_DV7 data scan migration
+	0065	L	P	D-View 8_System_D-View 7 Upgrade_DV7 Remote Probe automatic Upgrade
+	0066	L	P	D-View 8_System_About_About interface display
+	0067	L	P	D-View 8_System_About_Product Activation
+	**DKP2106013** -- TSD1_Switch_D-View8_Template			
+	0001	L	P	D-View8 Template - Device Template
+	0002	L	P	D-View8 Template - Device Template - Add
+	0003	L	P	D-View8 Template - Device Template - Add (Associate Panel Template)
+	0004	L	P	D-View8 Template - Device Template - Add (Associate Monitor Template)
+	0005	L	P	D-View8 Template - Device Template - Add (Associate Monitor Template default)
+	0006	L	P	D-View8 Template - Device Template - Query
+	0007	L	P	D-View8 Template - Device Template - View (Monitor/Panel Template default)
+	0008	L	P	D-View8 Template - Device Template - Modify
+	0009	L	P	D-View8 Template - Device Template - Download/Upload
+	0010	L	P	D-View8 Template - Device Support - Vendor (Add/Modify/Delete)
+	0011	L	P	D-View8 Template - Device Support - Device Category (Add/Modify/Delete)
+	0012	L	P	D-View8 Template - Device Support - Query
+	0013	L	P	D-View8 Template - Device Support - Vendor (Add/Modify/Delete)
+	0014	L	P	D-View8 Templates - Panel Template (Add/Modify/Delete)
+	0015	L	P	D-View8 Template - Panel Template - Download/Import

+	0016	L	P	D-View8 Templates - Monitor Template - Monitor Category (Add/Edit/Delete)
+	0017	L	P	D-View8 Templates - Monitor Template - Monitor Category
+	0018	L	P	D-View8 Templates - Monitor Template (Add/Edit/Delete)
+	0019	L	P	D-View8 Templates - Monitor Template - Download/Import
+	0020	L	P	D-View8 Templates - Configuration Template - Configuration Category - Add
+	0021	L	P	D-View8 Templates - Configuration Template - Configuration Category - Edit/Delete
+	0022	L	P	D-View8 Templates - Configuration Template - Configuration Category - Display
+	0023	L	P	D-View8 Templates - Configuration Template - Configuration Category - Query
+	0024	L	P	D-View8 Templates - Configuration Template - Configuration Template - Add
+	0025	L	P	D-View8 Templates - Configuration Template - Configuration Template - Edit/Delete
+	0026	L	P	D-View8 Templates - Configuration Template - Download/Import
+	0027	L	P	D-View8 Template - Configuration Template - Query
+	**DKP2106014** -- TSD1_Switch_D-View8_Cluster			
+	0001	L	N	Cluster Installation
+	0002	L	N	Cluster Upgrade
+	0003	L	N	Cluster Uninstall
+	0004	L	N	Probe Upgrade
+	0005	L	N	D-View8 function - Module function check
+	0006	L	P	D-View8 function - Activation function check
+	0007	L	P	D-View7 upgraded to D-View8 function check
+	0008	L	N	Cluster function
+	0009	L	N	Cluster function - Database Redundancy
+	0010	L	N	Stability - Database Service Exception and Recovery
+	0011	L	N	Stability - Network Abnormality and Recovery
+	0012	L	N	Stability - Core server Service Exception and Recovery
+	0013	L	N	Stability - Web server Service Abnormality and Recovery
+	0014	L	N	Stability - Server Downtime and Recovery
+	**DKP2106015** -- TSD1_Switch_D-View8_Other			
+	0001	L	P	D-View 8_Other_Log in to the D-View8 system normally
+	0002	L	P	D-View 8_Other_Login_Use the wrong username/password to login
+	0003	L	P	D-View 8_Other_Login_Forgot account password function verification
+	0004	L	P	D-View 8_Other_Login_Login for the first time to activate system function verification
+	0005	L	F	D-View 8_Other_Language Change_Change different Language function verification Summary Result: [Language Change][D-View 8/1.00.045] D-View 8 can't find Language Change function.
+	0006	L	P	D-View 8_Other_Sign out_Sign out of D-View8 system normally
+	0007	L	P	D-View 8_Other_Sign out_Sign out of D-View8 system automatically
+	0008	L	P	D-View 8_Other_Wizard_D-View 7 Upgrade_D-View 7 upgrade navigation function verification
+	0009	L	P	D-View 8_Other_Wizard_Discovery_Add and discover network navigation function verification
+	0010	L	P	D-View 8_Other_Wizard_Discovery_Automatically pop up the discovery navigation window
+	0011	L	P	D-View 8_Other_Wizard_Monitoring_Monitoring navigation function verification
+	0012	L	P	D-View 8_Other_Wizard_Alarm_Add Alarm and Notification function verification
+	0013	L	P	D-View 8_Other_User Profile_Account information view
+	0014	L	P	D-View 8_Other_User Profile_Account information modification
+	0015	L	P	D-View 8_Other_License_Verification of the number of days in the trial period
+	0016	L	P	D-View 8_Other_License_Trial version activation function verification
+	0017	L	P	D-View 8_Other_License_Use EnterpriseToTelecom to upgrade the system function verification
+	0018	L	P	D-View 8_Other_License_Use local files to activate system function verification offline
+	0019	L	P	D-View 8_Other_Compatibility_Firefox browser compatibility verification
+	0020	L	P	D-View 8_Other_Compatibility_Edge browser compatibility verification
+	0021	L	P	D-View 8_Other_Compatibility_Safari browser compatibility verification
+	0022	L	P	D-View 8_Other_Compatibility_Windows platform installation package verification

+	0023	L	P	D-View 8_Other_Compatibility_Linux platform installation package verification	
+	0024	L	P	D-View 8_Other_Compatibility_Windows platform upgrade package verification	
+	0025	L	P	D-View 8_Other_Compatibility_linux platform upgrade package verification	
+	0026	L	P	D-View 8_Other_Compatibility_Windows platform uninstall verification	
+	0027	L	P	D-View 8_Other_Compatibility_linux platform uninstall verification	
+	0028	L	P	D-View 8_Other_Compatibility_Windows platform server console program verification	
+	0029	L	P	D-View 8_Other_Compatibility_Windows platform basic function verification	
+	0030	L	P	D-View 8_Other_Compatibility_Linux platform basic function verification	
+	0031	L	P	D-View 8_Other_performance_User login performance test	
+	0032	L	P	D-View 8_Other_performance_Performance test of management equipment	
+	0033	L	P	D-View 8_Other_performance_Interface search performance test	
+	0034	L	P	D-View 8_Other_performance_Monitoring performance test	
+	0035	L	P	D-View 8_Other_performance_Alarm performance test	
+	0036	L	P	D-View 8_Other_performance_Configuration performance test	
+	0037	L	P	D-View 8_Other_performance_topo performance test	
+	0038	L	P	D-View 8_Other_performance_Periodic task performance test	
+	0039	L	P	D-View 8_Other_performance_Pressure test of the number of managed equipment	
+	0040	L	P	D-View 8_Other_performance_System stability test	

Create Date: 2021/06/25 17:50:38, By: Aaron Pan