



setup wizard - Microsoft Internet Explorer provided by ...

D-Link DWL-G700AP Setup Wizard

Set Wireless LAN Connection

Enter in the SSID name and Channel number to be used for the Wireless Access Point. Click **Next** to continue.

SSID

Channel ▼

Back Next Exit

setup wizard - Microsoft Internet Explorer provided by ...

D-Link DWL-G700AP Setup Wizard




If you wish to use encryption, enable it here and enter the encryption Key Values. Click **Next** to continue.

Wep Enabled Disabled

Wep encryption ▼

Key

Input 10 / 26 HEX characters(HEX is 0~9, A~F or a~f)



Back Next Exit

setup wizard - Microsoft Internet Explorer provided by ...

D-Link **DWL-G700AP Setup Wizard**

Setup Completed

The setup wizard has completed. Click **Back** to modify previous settings. Click **Restart** to save the current settings and reboot the DWL-G700AP

Back Restart Exit

DWL-G700AP



Wizard

Wireless

LAN

DHCP

Home

Advanced

Tools

Status

Help

Setup Wizard

The DWL-G700AP is a Wireless Access Point. The setup wizard will guide you to configure the DWL-G700AP. The DWL-G700AP's easy setup will allow you to have wireless access within minutes. Please follow the setup wizard step by step to configure the DWL-G700AP.

Run Wizard



Help

DWL-G700AP



Wizard

Wireless

LAN

DHCP

Home

Advanced

Tools

Status

Help

Wireless Settings

These are the wireless settings for the AP(Access Point)Portion.

SSID : default

Channel : 6

Authentication : Open System Shared Key

WPA-PSK WPA2-PSK

WPA WPA2

WEP : Enabled Disabled

WEP Encryption : 64Bit

Key Type : Hex (10 characters)

Key1 :

Key2 :

Key3 :

Key4 :



Apply



Cancel



Help

DWL-G700AP



Wizard

Wireless

LAN

DHCP

Home

Advanced

Tools

Status

Help

LAN Settings

LAN IP Dynamic IP Address
 Static IP Address

IP Address

Subnet Mask

Gateway

DNS Server

  
Apply Cancel Help

DWL-G700AP



Wizard

Wireless

LAN

DHCP

Home Advanced Tools Status Help

DHCP Server

The DWL-G700AP can be setup as a DHCP server to distribute IP addresses to the WLAN network.

DHCP Server Enabled Disabled

Starting IP Address

Ending IP Address

Lease Time



Apply **Cancel** **Help**

DHCP Client Table

Host Name	IP Address	MAC Address	Expired Time
None	----	----	----

DWL-G700AP



Performance

Filters

Home

Advanced

Tools

Status

Help

Beacon interval: (msec, range:1~1000, default:100)

RTS Threshold: (range: 256~2432, default:2432)

Fragmentation: (range: 256~2346, default:2346, even number only)

DTIM interval: (range: 1~255, default:3)

TX Rates:

Mode Setting: G Mode Mix Mode

Preamble Type: Short Preamble Long Preamble

SSID Broadcast: Enabled Disabled

Antenna transmit power:



Apply Cancel Help

DWL-G700AP



Performance

Filters

Home

Advanced

Tools

Status

Help

MAC Filters

Filters are used to allow or deny Wireless Clients users from accessing the DWL-G700AP..

- Disabled MAC Filters
- Only **allow** MAC address(es) listed below to connect to DWL-G700AP
- Only **deny** MAC address(es) listed below to connect to DWL-G700AP

MAC Address - - - - -

Connected PCs



Apply Cancel Help

MAC Filter List

MAC Address

DWL-G700AP



Admin

System

Firmware

Home **Advanced** **Tools** **Status** **Help**

Administrator Settings

New Password

Confirm Password

  
Apply Cancel Help

DWL-G700AP



Admin

System

Firmware

Home

Advanced

Tools

Status

Help

System Settings

Save Settings to Local Hard Drive

Save

Load Settings From Local Hard Drive

Browse...

Upload

Restore to Factory Default Settings

Reset



Help

DWL-G700AP



Admin

System

Firmware

Home Advanced **Tools** Status Help

Firmware Upgrade

There may be new firmware for your DWL-G700AP to improve functionality and performance and please check for an upgrade on our support site. To upgrade the firmware, locate the folder where the firmware was downloaded on the hard drive using the Browse button. Once you have found the file to be used, click the Apply button below to start the firmware upgrade.

Current Firmware Version: v2.00

Firmware Date: Thu, 8 Apr 2005

  
Apply Cancel Help

DWL-G700AP



Device Info

Log

Stats

Wireless

Home

Advanced

Tools

Status

Help

Device Information

Firmware Version **v2.00 Thu, 8 Apr 2005**

Ethernet

MAC Address 00:11:95:65:06:0c

IP Address 192.168.0.50

Subnet Mask 255.255.255.0

Gateway 0.0.0.0

DHCP Server Disabled

Wireless

SSID default

Encryption Function Disabled

Channel 6



Help