



## How to change the Wi-Fi name & password

**Step 1:** Open your web browser and type **10.0.0.2** into the address bar, then press Enter.



If your device is connected to the router, it will take you to a blue D-Link page asking for a username and password. Username is admin, password will either be admin, admin1 or personalized.



**Step 2:** Once logged in, navigate to

**Basic Setup → Wireless → Basic Configuration**



**Step 3:** Here you will see options for both the 2.4Ghz and the 5Ghz.

**SSID** will be your Wi-Fi name

**WPA Pre-share key** will be the password.

You can feel free to change it here.  
Scroll down and click on apply.

***Please note:*** all previously connected devices will now be disconnected, look for the new Wi-Fi name on your device and use the new password to connect.

## Wireless Basic Configuration 2.4GHz

Enable Wireless:	<input checked="" type="checkbox"/>
Choose SSID:	SSID1 ▾
Enable SSID:	<input checked="" type="checkbox"/>
Enable Isolation:	<input type="checkbox"/>
Hide SSID:	<input type="checkbox"/>
SSID:	dlink-957X-2.4G-b5ca
Maximum Clients:	32
BSSID:	A0:9F:7A:1F:B5:CB
Authentication:	WPA-PSK/WPA2-PSK MIXED ▾
WPA Pre-share key:	*****
Encryption Mode:	AES ▾

## Wireless Basic Configuration 5GHz

Enable Wireless:	<input checked="" type="checkbox"/>
Choose SSID:	SSID5 ▾
Enable SSID:	<input checked="" type="checkbox"/>
Enable Isolation:	<input type="checkbox"/>
Hide SSID:	<input type="checkbox"/>
SSID:	dlink-957X-5.8G-b5ca
Maximum Clients:	32
BSSID:	A0:9F:7A:1F:B5:CC
Authentication:	WPA-PSK/WPA2-PSK MIXED ▾
WPA Pre-share key:	*****
Encryption Mode:	AES ▾