

## [Basic Manual Setup for DWR-957X- How to configure as Bridge]

**Step 1:** Open your web browser and type **10.0.0.2** into the address bar, then press Enter.



If your device is connected to the router, it will take you to a blue D-Link page asking for a username and password. Default Username is admin, password is admin, unless it was updated.




**Step 2:** Once logged in, navigate to

**Basic Setup → WAN Service**



**Step 3:** Here you will see a table with three options, make sure to delete all three options, and under Set New WAN make sure mode is Bridge is selected. Click on create to continue.



**Step 4:** The following screen will appear. Here you have the option to give it a name, and make sure to enable it. Click on apply and the router will now be in bridge mode.

**D-Link® DWR-957X Home Gateway**

► Status  
Quick Setup  
▼ Basic Setup  
    WAN Service  
    ► LAN  
    ► Wireless  
► Advanced Setup  
► Applications  
► Management

### WAN Service

Connection Name:

Enable: ☐

IP Protocol Type:

Enable VLAN: ☐

Service Type:

#### Advanced Settings

VLAN PassThrough: ☐

DHCP Transparent: ☐

Bound Ports: ☐ LAN1 ☐ LAN2 ☐ LAN3 ☐ LAN4  
☐ SSID1 ☐ SSID2 ☐ SSID3 ☐ SSID4  
☐ SSID5 ☐ SSID6 ☐ SSID7 ☐ SSID8

A grey out port means it has been bound.

Apply Back Refresh