


## How to change router login password

**Step 1:** Open your web browser and type **10.0.0.2** into the address bar, then press Enter.



If your device is connected to the router, it will take you to a blue D-Link page asking for a username and password. Username is admin, password will either be admin, admin1 or personalized.



**Step 2:** Once logged in, navigate to

**Management → Account Management → Passwords**



**Step 3:** Here you will have the option to create a new password. Click on apply once done, the router will log out and you will have to use the new password to log back in.

## Account Management - Passwords

**Note:** Password cannot contain a space.

Username:	<input type="text" value="admin"/>
Old Password:	<input type="password"/>
New Password:	<input type="password"/>
Confirm Password:	<input type="password"/>
<input type="button" value="Apply"/> <input type="button" value="Refresh"/>	