



[G2562DX Changing Wi-Fi Name & Password]

The below steps will guide you to Manually Change the Wi-Fi Name & Password on the router.
(Please ensure you are connected to the router either on Wi-Fi or Ethernet cable)

- 1) Login to the device WEB GUI using 10.0.0.2 and Use Username: admin Password: admin/admin1.



- 2) Navigate to Basic Setup → Wi-Fi 2.4GHz/5GHz→ Basic
-Look for SSID→Enter a custom Wi-Fi name → once done click on Save & Apply.



- 3) Navigate to Basic Setup → Wi-Fi 2.4GHz/5GHz → Security → once done click on Save & Apply.

Basic Setup ^

WAN

LAN

Wireless ^

Wi-Fi 2.4GHz

Wi-Fi 5GHz

Easy Mesh

Advanced Setup v

Applications v

Management v

This page allows you to set up wireless security. Enabling WEP or WPA using encryption keys can prevent unauthorized access to your wireless network.

Basic

Security

Band Steering

ACL

Site Survey

WPS

Select SSID: dlink-G2562DX-2.4G-b5d8 v

Encryption: WPA2/WPA3 v

Authentication: ☐ Enterprise (RADIUS) ☒ Personal (Pre-Shared Key)

Cipher Suite: ☒ AES ☐ TKIP/AES

Management Frame Protection ☐ none ☒ capable ☐ required

Key Format: Passphrase v

Pre-Shared Key: v

Generate Wi-Fi QR code:

Generate

Reset

Save & Apply