

Quick Start Guide

R95

BE9500 Wi-Fi 7 Smart Router



x1





x1



x1



x1



<https://eu.dlink.com/support>



GPL Information
<https://tsd.dlink.com.tw/GPL>



Option 1

3 /





4 /



Option 2

3 /

Wi-Fi Name (SSID): R95-XXXX
Wi-Fi password: XXXXXXXXXXXX





4 /

<https://xxxx.devicesetup.net/>
(XXXX represents the last 4 characters of the MAC address)
Admin Password: XXXXXXXXXXXX



Option 3

3 /



4 /

<https://xxxx.devicesetup.net/>
(XXXX represents the last 4 characters of the MAC address)
Admin Password: XXXXXXXXXXXX

