D-Link®

MOBILE WIRELESS ROUTER
DIR-412

**QUICK
INSTALLATION
GUIDE**

CONTENTS OF PACKAGING

CONTENTS

MOBILE WIRELESS ROUTER
DIR-412

ETHERNET CABLE
CAT5

POWER ADAPTER
5V 2.5A

CD-ROM
INCLUDES TECHNICAL MANUALS

If any of these items are missing from your packaging, contact your reseller.

PRODUCT SETUP

EASY SETUP: 3G CONNECTION MODE

SWITCH TO 3G CONNECTION MODE

Move the mode switch on the DIR-412 to the **3G ROUTER** position. While in this mode, the DIR-412 will use the 3G modem to connect to the Internet.

INSTALL THE 3G USB ADAPTER

Plug the 3G USB modem into the USB port of the DIR-412.

CONNECT TO THE DIR-412

Plug one end of the Ethernet cable into the DIR-412. Plug the other end of the cable into your PC's Ethernet port. You may also connect to the router wirelessly.

CONFIGURE THE DIR-412

Open a web browser and go to **http://192.168.0.1**. Enter **admin** as the User Name, and leave the Password field blank. You may use the Setup Wizard to configure your DIR-412.

PRODUCT SETUP

EASY SETUP: WAN CONNECTION MODE

WAN

SWITCH TO WAN CONNECTION MODE
Move the mode switch on the DIR-412 to the **WAN** position. In this mode, the DIR-412 will function as a wireless router.

CONNECT TO A CABLE/DSL MODEM
Plug one end of the Ethernet cable into the DIR-412. Plug the other end of the cable into your cable/DSL modem.

CONNECT TO THE DIR-412
Use a PC with an active wireless adapter to open a web browser and scan for available wireless networks. Connect to the network with the SSID labeled **dlink**.

Login
D-Link
User Name XXXX
Password

CONFIGURE THE DIR-412
Open a web browser and go to **http://192.168.0.1**. Enter **admin** as the User Name, and leave the Password field blank. You may use the Setup Wizard to configure your DIR-412.

TROUBLESHOOTING

SETUP AND CONFIGURATION PROBLEMS

1. HOW DO I CONFIGURE MY DIR-412 MOBILE WIRELESS ROUTER WITHOUT THE INSTALLATION CD, OR CHECK MY WIRELESS NETWORK NAME (SSID) AND WIRLESS ENCRYPTION KEY?
- Connect your PC to the DIR-412 using an Ethernet cable.
- Open a web browser and enter the router address: **http://192.168.0.1**
- The default username is **admin**. The default password is blank (leave this box empty).
- If you have changed the password and cannot remember it, you will need to reset the router to factory defaults in order to set the password back to blank.

2. HOW DO I RESET MY DIR-412 MOBILE WIRELESS ROUTER TO FACTORY DEFAULT SETTINGS?
- Ensure that the DIR-412 is plugged in and receiving power.
- Press and hold the reset button on the rear of the device for 5 seconds.
  Note: Resetting the product to the factory default will erase the current configuration. To reconfigure your settings, log into the DIR-412 as outlined in question 1, then run the Setup Wizard.

3. HOW DO I ADD A NEW WIRELESS CLIENT OR PC IF I HAVE FORGOTTEN MY WIRELESS NETWORK NAME (SSID) OR WIRELESS ENCRYPTION KEY?
- For each PC that needs to connect to the DIR-412 wirelessly, you must ensure that the correct Wireless Network Name (SSID) and encryption key has been entered.
- Use the web based user interface (as described in question 1 above) to verify or choose your wireless settings.
- Make sure you write down these settings so that you can enter them into each wirelessly connected PC. You will find a dedicated area on the back of this document to write down this important information for future use.

4. WHY CAN I NOT GET AN INTERNET CONNECTION?
- Cable modem users must select the **Clone MAC Address** option during the installation Wizard or manually enter the registered MAC address, and ensure that the ISP username and password are correct.

TECHNICAL SUPPORT

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Australia:
Tel: 1300-766-868
24/7 Technical Support
Web: http://www.dlink.com.au
E-mail: support@dlink.com.au

India:
Tel: 1800-233-0000 (MTNL & BSNL Toll Free)
    +91-832-2885700 (GSM, CDMS & Others)
Web: www.dlink.co.in
E-Mail: helpdesk@dlink.co.in
        techsupport@dlink.co.in

Indonesia, Malaysia, Singapore and Thailand:
Tel: +62-21-5731610   (Indonesia)
Tel: 1800-882-880   (Malaysia)
Tel: +65 6501 4200   (Singapore)
Tel: +66-2-719-8978/9   (Thailand)
24/7, for English Support only
Web: http://www.dlink.com.sg/support/
E-mail: support@dlink.com.sg

Korea:
Tel: +82-2-2028-1815
Monday to Friday 9:00am to 6:00pm
Web: http://www.d-link.co.kr
E-mail: arthur@d-link.co.kr

New Zealand:
Tel: 0800-900-900
24/7 Technical Support
Web: http://www.dlink.co.nz
E-mail: support@dlink.co.nz

Egypt:
Tel: +202-2919035
    +202-2919047
Sunday to Thursday 9:00am to 5:00pm
Web: http://support.dlink-me.com
E-mail: support.eg@dlink-me.com

Iran:
Tel: +98-21-88880918,19
Saturday to Thursday 9:00am to 5:00pm
Web: http://support.dlink-me.com
E-mail: support.ir@dlink-me.com
         support@dlink.ir

TECHNICAL SUPPORT

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Israel:
Magshimim 20, Petach Tikva 49348
Main Tel: 972-3-9215173
Customer Support Tel: 972-3-9212886
Web: www.dlink.co.il

Pakistan:
Tel: +92-21-4548158
      +92-21-4548310
Monday to Friday 10:00am to 6:00pm
Web: http://support.dlink-me.com
E-mail: zkashif@dlink-me.com

South Africa and Sub Sahara Region:
Tel: +27-12-665-2165
      08600 DLINK (for South Africa only)
Monday to Friday 8:30am to 9:00pm South Africa Time
Web: http://www.d-link.co.za
E-mail: support@d-link.co.za

Turkey:
Tel: +90-212-2895659
Monday to Friday 9:00am to 6:00pm
Web: http://www.dlink.com.tr
E-mail: turkiye@dlink-me.com

U.A.E and North Africa:
Tel: +971-4-4278127 (U.A.E)
Sunday to Thursday 9.00AM to 6.00PM GMT+4
Web: http://www.dlink-me.com
E-mail: support.me@dlink-me.com

Saudi ARABIA (KSA):
Tel: +971-4-4278127 (U.A.E)
Sunday to Thursday 9.00AM to 6.00PM GMT+4
Web: http://www.dlink-me.com
E-mail: support.me@dlink-me.com

WIRELESS NETWORK REMINDER

Wireless Network Name (SSID)

Wireless Network Password