D-Link DSL-2750U Firmware Upgrade

Compiled by Marilize Truter D-Link Africa

POWER ADAPTER CONNECTION

■ **Plug the 3-Pin Power Supply/ Lightning Protection unit into the wall outlet and then connect the other end of it (12VDC IN**)

POWER UP
your Business

LAN CONNECTION

POWER UP
your Business

■ **Connect the Ethernet LAN Cable to any (yellow) port on the Router and connect the other end to the LAN port of the PC**

POWER UP
your Business

CONNECTING TO THE UNIT VIA WEB GUI

POWER UP
your Business

How to login to Unit using the Web GUI

1. Go to your Internet Explorer or Default Browser.

2. In your URL field, type the Default IP (10.0.0.2) of router.

3. A login page will appear and you will be prompted for a Username and Password these are both "admin"

Username: admin

Password: admin

If your username and password details are correct, you will be taken to the "Home Screen" from where you can navigate your way around.

Firmware Upgrade.

POWER UP
your Business

Once logged into the DSL-2750U click on *Maintenance* followed by *Firmware Update*.

Click on *Browse* and browse to the required firmware on your computer.

Gan5.CT02W-B-DL-R4B061-DAF.EN_upgrade(AF_1.61_T10)

Select the correct firmware file, then click on *Open*.

Select **Update Firmware**.

Once you have selected *Update Firmware*, the DSL-2750U will automatically Reboot.

D-Link
Building Networks for People

Confirm that the firmware upload was successful by looking at the upper right hand corner of your Web GUI or by selecting *Status* and then *Device Info*.

Please ensure to Logout each time an Upgrade has been Completed! You can achieve this by selecting *Maintenance* and then *Logout*.