D-Link

Setup Guides

[Basic Manual Setup for DWR-957X- How to force 4G only connection]

Step 1: Open your web browser and type **10.0.0.2** into the address bar, then press Enter.

If your device is connected to the router, it will take you to a blue D-Link page asking for a username and password. Default Username is admin, password is admin, unless it was updated.

Step 2: Once logged in, navigate to

Basic Setup → WAN Service

Step 3: Here you will see a table with three options, look for the one that says LTE and then click on edit

Step 4: The following screen will appear, click on advance settings.

WAN Service

Connection Name:	LTE
Enable:	☑
MTU:	1500
IP Protocol Type:	IPv4 ▾
NAT:	☑
Firewall:	☑
IPv4 Static DNS:	☐
MAC Address Override:	☐
Enable VLAN:	☐
Service Type:	TR069_INTERNET_VOIP ▾

Advanced Settings ⬅

Apply | Back | Refresh

Step 5: Look for where it says NetWork, currently it should be on auto, if you click on auto you will have the option to change it to 4g Only.

Advanced Settings

PIN:	
NetWork:	Auto ▾ ⬅
APN:	Other ▾
DialNumber:	*99#
Dial UserName:	any
Dial Password:	any
DHCP Option 60 Setting:	☐
DHCP Option 66:	☐
DHCP Option 120:	☐
DHCP Option 81 Setting:	☐
Bound Ports:	☐ LAN1 ☐ LAN2 ☐ LAN3 ☐ LAN4
	☐ SSID1 ☐ SSID2 ☐ SSID3 ☐ SSID4
	☐ SSID5 ☐ SSID6 ☐ SSID7 ☐ SSID8
	A grey out port means it has been bound.

Apply | Back | Refresh

Once you have changed it to 4G only, scroll down and click on apply, the router will now be locked to 4G only.